

315 (3 Stage RO Unit with Sticker)

1. Undo both 10" housings.

Remove packaging covers from both carbon filters.

2. Lubricate both 10" Filter Heads & Membrane Housing O Ring.

3. Fit Membrane & Filters.

4. Tap connection is **REAR** of Bracket.
Tank connections is **FRONT**.

5. Flush Membrane with Flow Controller by-pass valve Open for *30 Mins*.

6. Shut Flow Controller & Place **4 dry wipe marks on the Bracket**.

7. Make sure faucet **tap is closed** and allow **tank to fill**.

8. Once tank is full ensure **drain line stops** running.

9. **Open faucet** tap & allow to run until **flow is a trickle**.

10. Remove one dry wipe mark and repeat Fill and Flush routine 3 more times.